



## **Manual for the Feathering Propeller**

### **DF-230 and DF-280**

3 blade model

Installation on the shaft	page 2
Operation	page 3
Removing from the shaft	page 4
Servicing	page 5
Torque settings prop-nut	page 6


# INSTALLATION on the shaft

**The VARIPROP is delivered assembled, greased and ready for installation.**


Before fitting the VARIPROP onto the shaft, check key and keyway in the propeller hub. Take care that the key is the proper dimension and that the hub slides completely onto the shaft (see below). Also check the nut on thread of the shaft before fitting the prop. If you can not screw the nut the complete length of the thread, because of a little damage to the thread, carefully use a triangle file to bring it down to a good fit.

Remove the housing cap with zinc anode (2) and the nut (4). Fit the propeller onto the shaft strongly. Tighten the nut (4) with LOCTITE low (pink) onto the shaft ( torque-setting see page 6 ) and secure it with the lock pins (3). Fit the housing cap with anode (2).

Make sure that the propeller is always protected from electrolytic corrosion by changing the anode (2) latest every year! After the VARIPROP has been fitted properly check that the blades rotate freely from the forward stop to the reverse stop.




**MOUNTING:** First slide the prop on the shaft without key. Mark the shaft with a grease-pen at the prop end. After tightening the shaft nut very strongly ( torque-setting see page 6 ) the mark must disappear. If not, the key is binding and the top or the sides of the key must be filed down. Light must be shining through on the top of the key when looking into the hub from astern. You may have to move your eye vertically to see it.



**Only two** of the three lock-pin holes can be used, depending on the final position of the shaft-nut flange ( 3 ).

Carefully align the lock-pins (3) straight. They must go in easily. If not, try first to tighten the propnut a little further until they do. If impossible, back off the nut a little. The lock-pins should be hand tightened only. If overtightened they may strip.



## **ATTACHING THE HOUSING CAP with ZINC-ANODE:**

First, insert all three housing cap screws (1, also page 4) loosely, then tighten securely in succession. Use LOCTITE low (pink) and observe the little washers.

## **ENGINE DRY TEST:**

Please consider that a dry test of the engine **MUST NOT** be done while the VARIPROP is fitted onto the shaft ! The VARIPROP needs water pressure on the blades, otherwise the prop could be damaged !!

# OPERATION

The Variprop feathers automatically when the shaft rotation is stopped. After engine start-up and shifting into gear the blades will engage in either forward or reverse.

## THE BEST WAY TO FEATHER THE PROPELLER IN THE SAILPOSITION IS:

### VARIPROP sailposition with mechanical gear-box:

- + Power at 3 to 4 knots in forward.
- + **Stop the engine, turn it off** and engage the transmission in reverse to stop the freewheeling of the shaft. Now engage in Neutral again.

### VARIPROP sailposition with hydraulic transmission:

- + Power at 3 to 4 knots in forward.
- + Stop the engine while still engaged in forward. The remaining oil pressure of the transmission will stop spinning the shaft to feather the blades in the sailposition.

If the propeller is not feathered in the sailposition the shaft will freewheel like with a fixed propeller.

In that case start the engine again and repeat the steps above.

Once the prop is feathered, it is better to shift the transmission to neutral.

**DO NOT stop** the engine while it turns in reverse. In this case the blades will stay in the reverse position and will not feather. You can actually use this feature to drive a shaft generator.


**TROUBLE SHOOTING:** If the propeller does not work in forward or reverse go systematically through the points below:

- + Check low idle of the engine. It should be 800 to 900 rpm in idle.
- + Check shifting movement of the transmission lever. Make sure that the shifting travel is not too short. The amount of lever travel, as measured at the pivot point of the actuating lever, between the neutral position and end positions for forward and reverse can be found in the owners manual of your transmission. A larger amount of lever travel is in no way detrimental.
- + Check the clutch discs of the transmission. They could be worn out.

**WARNING:** It is important to follow the instructions below carefully so as to avoid excessive load and shock to the gears, shortening their life.

- + When going from ahead to astern or the opposite, it is necessary to idle down and shift at low rpm's (max.1200rpm) between gears to allow smooth reversing of rotation without binding. This will substantially lengthen the service life of your propeller gears.
- + When going from ahead to astern or the opposite, you can hear the turning-noise of the feathering blades. This is normal and not a problem or a defect of your VARIPROP.
- + The propeller body must always be completely filled with a high viscosity grease. We recommend synthetic grease typ TW.2 GEL or mineral multi-purpose grease EP/SAL 8 (see servicing page 5 )
- + The propeller must be protected from electrolytic corrosion by fitting the usual zinc anodes on the shaft plus the prop anode.
- + If you want to protect your VARIPROP with Antifouling, use only Antifouling which needs a primer first. Otherwise chemical interaction and decomposition could occur. Our recommendation is *Velox TF plus* including a primer, available from your VARIPROP distributor.

# VARIPROP REMOVAL



The puller system is delivered with the VARIPROP.  
The system includes only two parts :

- (1) The puller nut and
- (2) the hexagonal head bolt



- 1.) In order to remove the Variprop you must first remove the housing cap with zinc anode.
- 2.) Remove both lock pins (3) and the prop nut (4, see page 2)



- 3.) Screw the puller nut **completely** into the hub




- 4.) Now screw the hexagonal head bolt into the nut and turn the bolt against the shaft until the VARIPROP comes off the taper.  
Never use a hammer to remove the prop from the taper !

**NOTE :** Never dismantle the VARIPROP yourselves !!  
Disassembly and reassemble require special tools and technical know-how only available at the factory or their approved service centres.

# SERVICING

The VARIPROP needs to be greased up a minimum of every 2 – 3 years, depending on the engine hours run, or whenever the boat is hauled. The VARIPROP body should always be completely filled with a high viscosity **grease** of a hydrophobic nature. Remove the cap screw **(5)** and screw in the lubricating nipple which is supplied with the tools. Remove the “grease out” screw **(6)**. During filling with grease rotate the propeller from forward stop to reverse stop to allow the grease to work through the propeller. Stop to pump when grease comes out at the opened “grease out “ port.



Factory supplied special grease EP/SAL is recommended and available from your VARIPROP distributor.  
**Avoid regular white grease (sterntube-grease) !**

**Zinc anode:** Make sure that you always keep the zinc anode in good condition. The Variprop must be protected by a lot of zinc, so also use a zinc anode onto the shaft if possible. Use fine sandpaper to clean the aft of the end boss and the forward face of the Variprop-anode to give the zinc good contact with the propeller.

Tools supplied with your VARIPROP DF-230 / 280:



1x Manual  
1x puller system  
1x allen key 4mm  
1x allen key 6mm  
1x allen key 8mm  
1x grease nipple G1/4"  
1x small plastic bottle with Loctite low (pink)

# Torque settings for the prop-nut

( page2, Fig.1, part-no.4 )

## Standard – thread

M 20 x 2,5 BSW 3 / 4 " – 10 UNC 3 / 4 " - 10	125 Nm / 95 ft/lb
--	-------------------

UNC 7 / 8" - 9	160 Nm / 115 ft/lb
----------------	--------------------

M 24 x 3 BSW 1 " - 8 UNC 1 " - 8	210 Nm / 155 ft/lb
--	--------------------

M 27 x 3	315 Nm / 230 ft/lb
----------	--------------------

M 30 x 3,5 BSW 1 1/8" – 7 UNC 1 1/8" - 7	350 Nm / 255 ft/lb
--	--------------------

UNC 1 ¼" – 7 BSW 1 1/4" - 7	350 Nm / 255 ft/lb
--------------------------------	--------------------

UNC 1 1/2" - 6	390 Nm / 290 ft/lb
----------------	--------------------

## Fine - thread

M 20 x 1,5 BSF 3 / 4 " – 12 UNC 3 / 4 " - 16	135 Nm / 100 ft/lb
--	--------------------

M 24 x 2 BSF 1 " - 10 UNF 1 " - 12	225 Nm / 165 ft/lb
--	--------------------

M 30 x 2	430 Nm / 315 ft/lb
----------	--------------------

M 36 x 3	490 Nm / 360 ft/lb
----------	--------------------

M 42 x 3	530 Nm / 390 ft/lb
----------	--------------------

SUBJECT TO TECHNICAL ALTERATIONS; ERRORS and MISPRINTS